



Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: <http://dhollift.nt-rt.ru> || dnh@nt-rt.ru

DH-VB

Колонный подъемник

Технические характеристики



→ Column lift for trucks, trailers & semi-trailers

DH-VB... • 750 - 2500 kg



Multi-deck column lift with upper beam

The DH-VB... are specially designed to load and unload vehicles with multiple or moving loading floors. All DH-VB... are equipped with a flat platform, offering a smooth and level ride from the various loading floors to the ground (and vice versa).

The DH-VB... have a cylinder beam at vehicle roof level. These **heavy duty lifts** are suitable for vehicles with **insufficient ground clearance to mount a DH-VO lower beam lift** (too low vehicle floor level); and for applications with a considerable **risk that harmful products could penetrate in the cylinder beam** (e.g. animal transport).

Upper beam lifts are available in various models, and for different capacity classes. All exterior lifts are equipped with 2 tilt cylinders, hence the platform orientation is adjustable from the exterior controls. The most common lift models are:

DH-VB25.D2 • 1000 - 2500 kg (old name = DH-VB3)

- Basic model, robust & heavy duty, multi-functional
- Height of cylinder beam = 230 mm
- Platform = steel frame + aluminium infill profiles
- Lifting height to approx. 1380 mm under the roof level (*)

DH-VBV.25.D2 • 1000 - 2500 kg (old name = DH-VBV)

- Special adaptation for the transport live animals
- Height of the cylinder beam = 150 mm
- Platform = full aluminium platform
- Lifting height to approx. 1205 mm under the roof level (930 mm with option OVF001) (*)

DH-VB10.D3 • 750 - 1000 kg (old name = DH-VB5A)

- Light weight execution
- Height of the cylinder beam = 180 mm
- Platform = steel frame + aluminium infill profiles
- Full aluminium platform as option (OVP004)
- Lifting height to approx. 540 mm under the roof level (290 mm with option OVF001) (*)

(*) See remark 1 on pg. 165 reg. the achievable lifting height

Options: all DH-VB... offer a wide choice of options to adapt the lift to the specific requirement of each and every customer: safety rails on 2, 3 of 4 sides; roll-stops or hinged ramps; side loading ramps; foldable or slide-out ramps at the rear edge of the platform, etc...



Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Саратов (845)249-38-78	Ярославль (4852)69-52-93

Единый адрес для всех регионов: <http://dhollift.nt-rt.ru> || dnh@nt-rt.ru